

Tent Peak Flag Kit

Assembly Instruction

FABRIC

Tent Top - 600D PU Polyester
Peak Flag - 100D Polyester

SIZE

Tent - 10'x10' (40mm Hex)
Peak Flag - 18"x59"



1 Lay all parts on floor



2 Remove the top pole from the tent frame first, then insert the supplied flag holder



3 Unfold the tent frame and cover the tent top on it



4 Connect the 2 long tubes to get a vertical flag pole



5 Insert the plastic cap onto the pole




6 Insert the vertical pole into the side pole pocket, and the shorter pole the top pole pocket



7 Mount flag on the top of the roof of tent and fasten with the plastic cap



8 Adjust the tent to proper height



9 The installation is complete.