

Square Tent Billboard Banner


Assembly Instruction

FABRIC

180g Elastic Polyester

SIZE

96"x23.6" (244x60cm)



1 Lay all parts on the floor



2 Connect one long tube with two short tubes to get a longest pole



3 Insert the longest pole to the pocket first



4 Then insert the rest 2 poles to the side pockets respectively



5 Use connectors to connect the horizontal pole and vertical poles



6 Attach the banner to the tent legs and then secure with the clamps



7 Adjust the banner height by sliding the clamps up or down