Advance

ADV-800-S

With refined styling and a streamlined profile, the Advance is packed with new design innovations. Useable as a single or double sided system, this removable cassette banner system has been specially designed for maximum convenience and ease of use.











New Banner Stand Accessories: easy connection with cam lock and channel

We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights guoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

features and benefits:

- Variable height = 29.5" 83.35"
- **New** telescopic pole
- New integrated pole storage for the twist & lock Interchangable graphic cassettes telescopic pole
- New accessory channel featured on the top of the unit (to add a literature pocket or arm table accessorv)

dimensions:

Hardware

Assembled unit:

87"(h) max x 34.25"(w) x 11.61"(d) approx. 2210mm(h) x 870mm(w) x 295mm(d) approx.

Base dimensions:

3.75"(h) x 34.25"(w) x 11.61"(d) approx. 95mm(h) x 870mm(w) x 295mm(d) approx.

Weight:

16.8 bs/7.66kg approx. (including carry bag) (Installed graphics will add weight)

Shipping

Shipping dimensions - ships in one box 37"(h) x 14"(w) x 5"(d) 920mm(h) x 350mm(w) x 115mm(d)

Approximate shipping weight:

24lbs/10.89kg shipping weight with graphic approx.


17lbs/7.66kg shipping weight without graphic approx.

additional information:

Graphic materials: 14oz. anti-curl vinyl, 8oz. oxford, 11 mil melinex

Stand-off rectangle counter top is available in black thermoform only.

Stand-off literature rack is available (L112-2 only)



- Graphic tensioner
- Add your own branding using the slide in graphic channel along the banner stand base
- Premium form molded EVA bag included
- Lifetime warranty against manufacturer defects

Graphic Visible dimensions:

83.35" max(h) x 31.50" (w) 2130mm(h) x 800mm(w)

29.5" min(h) x 31.50" (w) 749mm(h) x 800mm(w)

Grippa top rail attachment recommended for semi-permanent or long term use. Adhesive top rail attachment recommended for short term use

WARNING: Always attach graphic to base and top rail before removing the locking pin. After fitting, the graphic should be left for 24 hours before use to ensure the adhesive bonds sufficiently. Opening the base will invalidate the product warranty.

Graphic tension may be re-applied or added by turning the ratchet tensioner clockwise.



Lumina 2 banner lig	hting option	available
---------------------	--------------	-----------

