



INSTALLATION STEPS


Step 1

Gather all 4 of the extrusions and lay them out on a flat surface. The extrusions will be linked together using the lock and pressure plates.




Step 4

Repeat step 3 on the back side of the extrusion. Then repeat the same step on the opposite end.



Step 7

Repeat steps 2-5 for the last remaining extrusion. Tighten all socket screws with the 3mm allen key.




Step 10

Align the insert holes in the T-legs to the pre-drilled holes in the extrusions. Insert the bolts through the T-legs and then the extrusion, respectively.



Step 2

Align the lock plate and pressure plate together. Make sure that the socket screws are recessed enough so the two pieces sit flush together.



Step 5

Slide in both adjacent extrusions. These extrusions should match as a pair in length.



Step 8

The frame is complete and is now ready for both T-legs to be installed.



Step 11

Once the bolt is completely inserted, screw on the wing nut and then tighten. Repeat the process until both T-legs are securely attached.



Step 3

Insert the aligned pieces completely into the slot. Insertion begins at either end of the extrusion. DO NOT TIGHTEN the socket screws.



Step 6

Make sure the corners of the extrusions are flush.




Step 9

Locate the (2) pre-drilled holes on the outside of the left and right extrusion.



Step 12

Screw in the leveling feet and then stand the frame up. Your frame is ready to be fitted with the silicone edge graphic.



(2nd FOLD HERE)

(1st FOLD HERE)